BEAM
MUON WALL AT BEAMLINE
PNEU. VALVE
PASS VALVE
VCY.CV1 (YCOR)
QV01 (QUAD)
(MpB) BPMVBR
QV02 (QUAD)
(MpB) BPMVBR
URCX01 VMCX
BY3 (BEND)
EVACUATE VALVE
I-P-1 NON PUMP
QD01 (QUAD)
(MpB) BPMVBR
RCX01 (VB1) VCX
I JUDGE VAC
RCX02 (VB2) VCX
I-P-2 NON PUMP
BTB
QV03 (QUAD)
(MpB) BPMVBR
QV04 (QUAD)
(MpB) BPMVBR
MS1 (TORO)
MBC31 (TORO)
2-P-1 SUPPORT VAC
ION PUMP 3
2-P-2 SUPPORT VAC
2 SUPPORT VAC
RCX03 (YCX)
QD03 (QUAD)
(MpB) BPMVBR
YCX.L1 (YCOR)
CED.L1 (YCED)
I-P-4 NON PUMP
PNEU. VALVE
5-P-3 NON PUMP
(LTU SECTION T1) (D-380-036-03)
(LTU SECTION T2) (D-380-036-04)
(LTU SECTION T3) (D-380-036-05)
(BEGIN SECTION T4) (D-380-036-06)
(LTU SECTION T4) (D-380-036-06)
(LTU SECTION T5) (D-380-036-07)
(LTU SECTION T6) (D-380-036-08)
(LTU SECTION T7) (D-380-036-09)
(BEGIN SECTION T8) (D-380-036-10)
(LTU SECTION T8) (D-380-036-10)
(LTU SECTION T9) (D-380-036-11)
(LTU SECTION B0) (D-380-036-12)
(LTU SECTION B1) (D-380-036-13)
(LTU SECTION B2) (D-380-036-14)
(LTU SECTION B3) (D-380-036-15)
(LTU SECTION B4) (D-380-036-16)
(LTU SECTION B5) (D-380-036-17)
(LTU SECTION B6) (D-380-036-18)
(LTU SECTION B7) (D-380-036-19)
(LTU SECTION B8) (D-380-036-20)
(LTU SECTION B9)